

Hidrive SOP (Standard Operational Procedure)

DOOR CLOSING - BI-FOLD

Easy as 1,2,3

STEP ONE.

Use the door handle to bring the Bi fold door down to the top of the first stage of the hinge movement.

STEP TWO.

With one hand still holding the handle, a second hand should be placed palm down on the door above the bifold joint to enable more downward pressure to bring the door through the early part of the door's arc.

STEP THREE.

As the door passes the median part of the arc, your assisting hand will transition from a pulling to a pushing motion in a single smooth comfortable arm movement and your shoulder rotating in one simple plain. Once fully closed, turn the handle to engage the latch.



hidrive

www.hidrive.com.au



Hidrive SOP (Standard Operational Procedure)

DO NOT'S

Do not pull the door down to the first section without using the handle as it will cause unnecessary reach and strain on the operator.



Do not close the door the whole way with the handle as it causes strain on operators' shoulders and back.



hidrive

www.hidrive.com.au

JAS-ANZ



ISO 9001 QUALITY
Certified System