





## **BATTERY PROTECTION**

Battery protection disconnects crank batteries from non-essential loads before it is completely discharged.

## **Features & Benefits:**

- Maintains a minimal level of charge for vehicle batteries
- Safety mechanism to prevent vehicle battery going flat
- Can be configured to suit non-essential loads specific to your needs

## **Details:**

 $\odot$  Compatibility Truck

○ Warranty 12 Month

manufacturers

warranty

**VIEW ONLINE** 





Chat with one of our helpful Mobile Workspace Specialists.

- **→ 1300 350 625**
- → team.aus@hidrive.com.au
- → hidrive.com.au



Hidrive is the only manufacturer of service bodies for utes, trailers and trucks with a company-owned national installation network.



Eastern Manufacturing, Installation & Showroom 17 O'Sullivan Pl, Goulburn NSW 2580



Brisbane Showroom & Installation 146 Crockford St, Northgate QLD 4013



Melbourne Showroom & Installation 57 Hunter Rd, Derrimut VIC 3026



Western Manufacturing, Installation & Showroom 18 Catalano Rd, Canning Vale WA 6155



Sydney Showroom & Installation 10 Garner PI, Ingleburn NSW 2565











© Hidrive May 2024. All rights reserved. Errors & omissions excluded. Hidrive reserves the right to change specifications and models without notice.