





JUMPSTART RECEPTACLE (TRUCK)

Ideal for use on applications where access to battery terminals is restricted on the worksite or in remote locations.

Options:

- Dual battery, 12V
- Dual battery, 12V + 24V
- Crank battery

Features & Benefits:

- A Jumpstart Receptacle is essentially an Anderson Plug connected to either the Vehicle Crank Battery or an Auxiliary Dual Battery, allowing other vehicles or equipment to be easily and safely jump started
- The receptacle eliminates the need for connecting jumper leads to your battery, you simply plug in leads and connect to the vehicle or equipment you are jump starting
- The receptacle is ideally mounted as close as possible to the battery (crank battery or dual battery), generally external to the canopy to allow easy access

Details:

 ○ Compatibility Truck

○ Warranty 12 Month

manufacturers

warranty

VIEW ONLINE





JUMPSTART RECEPTACLE (TRUCK) Dual battery, 12V



JUMPSTART RECEPTACLE (TRUCK) Dual battery, 12V + 24V



JUMPSTART RECEPTACLE (TRUCK) Crank battery



Chat with one of our helpful Mobile Workspace Specialists.

- **→ 1300 350 625**
- → team.aus@hidrive.com.au
- → hidrive.com.au



Hidrive is the only manufacturer of service bodies for utes, trailers and trucks with a company-owned national installation network.



Eastern Manufacturing, Installation & Showroom 17 O'Sullivan Pl, Goulburn NSW 2580



Brisbane Showroom & Installation 146 Crockford St, Northgate QLD 4013



Melbourne Showroom & Installation 57 Hunter Rd, Derrimut VIC 3026



Western Manufacturing, Installation & Showroom 18 Catalano Rd, Canning Vale WA 6155



Sydney Showroom & Installation 10 Garner PI, Ingleburn NSW 2565











© Hidrive May 2024. All rights reserved. Errors & omissions excluded. Hidrive reserves the right to change specifications and models without notice.